

'19+ **EDGE ST 2.7L**

BLOW OFF VALVE ADAPTOR INSTALLATION



TOOLS REQUIRED

**5MM ALLEN KEY
10MM DEEP SOCKET**

STEP #1

LOCATE FACTORY BYPASS VALVE ON CHARGE PIPE AND DISCONNECT WIRE HARNESS. UNSCREW THREE SCREWS.

STEP #2

INSTALL THE BOOMBA RACING BOV ADAPTOR IN BETWEEN THE FACTORY BYPASS VALVE AND CHARGE PIPE USING PROVIDED LONGER SCREWS.

STEP #3

RECONNECT THE WIRING HARNESS AND GO FOR A DRIVE, ENJOY YOUR NEW BOV ADAPTOR!

