

BRONCO/RANGER RAPTOR BLOW OFF VALVE ADAPTOR

TOOLS REQUIRED

E5 Socket
M5 Allen Key
Ratchet

MATERIALS REQUIRED

1	Remove wire harness and torx bolts on OEM bypass valve.	2	Remove the OEM bypass valve.
			